



Wall Mounted Shower System Installation

Step 1 (Body Valve)

Parts List			Installation diagram													
<table border="1"> <tbody> <tr> <td>4</td> <td>expansion bolt</td> <td>4</td> </tr> <tr> <td>3</td> <td>board</td> <td>1</td> </tr> <tr> <td>2</td> <td>handle</td> <td>4</td> </tr> <tr> <td>1</td> <td>faucet body</td> <td>1</td> </tr> <tr> <td>NO.</td> <td>Name</td> <td>Quantity</td> </tr> </tbody> </table>	4	expansion bolt		4	3	board	1	2	handle	4	1	faucet body	1	NO.	Name	Quantity
4	expansion bolt	4														
3	board	1														
2	handle	4														
1	faucet body	1														
NO.	Name	Quantity														
<p>1. Please screw the handles out according to the above direction.</p>				<p>2. Take board and four handles out of the faucet body</p>												




7




7. Take gaskets and spring gaskets onto the tapping screws. And then lock the nuts by copper sleeve wrench.

8




8. Connect hot & cold supply water pipes (not provided) and other water pipes. After that, open the water to test if all pipes have leakage or not. At last, seal the wall.

9



9. Take the board onto the faucet body.

10



10. Screw the handles into the handwheels.

